

RS485 Index Command List.

PosCon OXH7.



 Baumer
Passion for Sensors



Contents

1	Introduction	3
1.1	UART Interface Settings	3
2	Command Structure	3
3	Index Command List	4
3.1	Application Errors	4
3.2	Device identification.....	4
3.3	Communication features.....	5
3.4	User interface features	5
3.5	Measurement features.....	6
3.6	Flex mount	7
3.7	Output configuration	8
3.8	Diagnosis features	8
3.9	Configuration storage features	9
4	Example commands	13
5	Appendix.....	14
5.1	Dependencies.....	14
6	History of changes	15



1 Introduction


This manual supplements the manual "RS485 Protocol Structure" and is valid for the Baumer PosCon HM sensors.

1.1 UART Interface Settings

Index Command	Value
Baud rate at power up	57600
Databits	8
Startbit	1
Stopbit	1
Parity	Even

2 Command Structure

An RS485 command is structured as follows.



The information to be transmitted is called PAYLOAD and has to be sent in a so-called frame so that the command can be recognized and processed.

This frame always has the same structure and contains a start, a device address, a PAYLOAD, a checksum and an end.

START	DEVICE ADDR	PAYLOAD	CHECKSUM	END
1 char	2 char	n char	4 char	2 char
:	01...99	Index Command List	****	\r\n

3 Index Command List

Values marked with * are the Factory settings

The diagram shows a table row for the 'Baudrate' command. Four callout boxes point to specific fields: 'Index' points to the first column (value 6), 'Read/Write' points to the second column (RW), 'Content' points to the third column (UINT8), and 'Can be stored' points to the fifth column ('Stored in configuration yes'). Below the table, four more callout boxes point to the fourth column: 'Empty' points to the first row (empty), 'Offset' points to the second row (value 0), 'Data Type' points to the third row (UINT8), and 'Description (here 0 stands für 38400....)' points to the fourth row (values 0, 1, 2).

6 (0x6)	RW		Baudrate Communication baud rate	Stored in configuration yes
	0	UINT8	0 38'400 1 * 57'600 2 115'200	

3.1 Application Errors

0 (0x0)	R		Application error Contains the application error code of the last command. If an application error occurs, it is signalled using the underlying protocol. The error code has to be read immediately after the error is signalled. It will be overwritten by any other command.	Stored in configuration no
		UINT32	Application error 0 no error 1 value not accessible 99 argument out of range 100 distance out of range 101 angle out of range 102 flatness out of range 103 length out of range	

3.2 Device identification

1 (0x1)	R	UINT32	Vendor info Vendor information Vendor id 1 Baumer Electric AG	Stored in configuration no
		STRING 65	Vendor name default: Baumer Electric AG	
2 (0x2)	R		Device info Device information	Stored in configuration no
		UINT32	Device id	
		UINT32	Product id Material number	
		STRING 65	Sensor type Eg. OXE7.E25T-MB3E.SIMD.A7	

		STRING 15	Serial number 1234567890AB	
--	--	--------------	-------------------------------	--

3.3 Communication features

5 (0x5)	RW	UINT8	Bus address Bus address Value range: 1 . . . 99	Stored in configuration yes
6 (0x6)	RW	UINT8	Baudrate Communication baud rate Baudrate 0 38'400 1 * 57'600 2 115'200	Stored in configuration yes

3.4 User interface features

10 (0xA)	RW		RS485 lock Access lock for RS485. If the lock is activated, the sensor can be controlled using the touch buttons and all RS485 commands will be rejected (except access to this index). If the lock is deactivated, the sensor can be controlled using RS485. In this case, all physical outputs (analog, switching and alarm out) will be deactivated and the LEDS will be set to a fixed state.	Stored in configuration no
		UINT8	RS485 lock 0 Lock deactivated 1 * Lock activated	
11 (0xB)	RW	UINT8	Output reactivation If enabled, the physical outputs (analog, switching and alarm out) will be re-enabled. Be aware that using physical outputs and RS485 simultaneously may lead to interferences. When RS485 lock is active, the outputs are also activated regardless of this index. Output reactivation 0 * Outputs deactivated 1 Outputs activated	Stored in configuration yes
15 (0xF)	RW		Display language Display language 0 * English 1 German 2 Italian 3 French	Stored in configuration yes
16 (0x10)	RW		Display backlight	Stored in configuration yes

		UINT8	Display backlight 0 * 5 min Display backlight switched off after 5min inactivity. 1 10 min Display backlight switched off after 10min inactivity. 2 20 min Display backlight switched off after 20min inactivity. 3 Always on Display backlight is never switched off.	
--	--	-------	---	--

17 (0x11)	RW		Touch button lock	Stored in configuration yes
		UINT8	Touch button lock 0 * Touch buttons not locked 1 Touch buttons locked	

3.5 Measurement features

20 (0x14)	RW		Measurement type selection	Stored in configuration yes
		UINT8	Measurement type selection Measurement type to use for all outputs (Analog output, Digital output, LED's). 13 Height (AVG) 14 Height (MAX) 15 Height (MIN) 16 * Height (MAX-MIN)	

21 (0x15)	R		Measurement value Measurement value selected by the "Measurement type selection" index.	Stored in configuration no
		FLOAT32	Measurement value [mm]	
		UINT8	Quality Quality of the optical input signal. 0 Valid 1 Low signal 4 No signal	

22 (0x16)	R		All measurement values Get all available measurement values according to selected measurement type. This index can only be read if precision is set to "standard".	Stored in configuration no
		FLOAT32	Average	
		FLOAT32	Max	
		FLOAT32	Min	
		FLOAT32	Delta	
		FLOAT32	Standard deviation	
		UINT8	Quality 0 Valid 1 Low signal 4 No signal	

30 (0x1E)	RW		Field of view Lateral measuring field	Stored in configuration yes
		INT16	Limit left	

			Field of view left limitation [mm].	
		INT16	Limit right Field of view right limitation [mm].	

31 (0x1F)	W		Set field of view to MAX command Sets the field of view to its maximum values.	Stored in configuration no
		UINT8	Set field of view to MAX command 1 Set field of view to MAX	

32 (0x20)	RW		Object type Adjust the exposure time for either dark target objects or bright target objects. Selecting DarkObject will lead to a longer measurement cycle.	Stored in configuration yes
		UINT8	Object type 0 * Bright object 1 Dark object	

33 (0x21)	RW		Precision Adjust the filtering of the measured values.	Stored in configuration yes
		UINT8	Precision 0 * Standard 1 High 2 Very high	

34 (0x22)	RW		Laser off data hold If activated, the measurement will be suspended and the laser is switched off. All outputs will hold the current value. The teach flex mount command and the diagnose mode (index 37, 50) are disabled. If deactivated, the measurement will continue.	Stored in configuration no
		UINT8	Laser off data hold 0 * Measurement is running 1 Measurement is holding	

3.6 Flex mount

35 (0x23)	RW		Flex mount enable See operating instructions for details.	Stored in configuration yes
		UINT8	Flex mount enable 0 * Disabled 1 Enabled	

36 (0x24)	RW	FLOAT32	Set flex mount See operating instructions for details. Angle Flex mount rotation angle [deg].	Stored in configuration yes
		FLOAT32	Distance Flex mount offset distance [mm].	

37 (0x25)	W		Teach flex mount command See operating instructions for details.	Stored in configuration no
		FLOAT32	Reference correction	



		[mm]
--	--	------

3.7 Output configuration

40 (0x28)	RW		Digital output configuration Settings of the digital output pin.	Stored in configuration yes
		FLOAT32	Switch point 1 [mm]	
		FLOAT32	Switch point 2 [mm]	
		UINT8	Digital output type 0 * Point 1 Window	
		UINT8	Digital output polarity 0 * Active high 1 Active low	

41 (0x29)	RW		Analog output configuration The analog output can be set as current or voltage output.	Stored in configuration yes
		UINT8	Analog output type 0 * Current 1 Voltage	
		UINT8	Analog output slope Slope of the analog characteristic curve. Can be positive (minimum output at minimum measurement value, fullscale output at maximum measurement value) or negative (vice versa). 0 * Positive 1 Negative	

42 (0x2A)	RW		Analog output scaling Points within the measuring range where the analog output value reaches its minimum/ full scale value (depends on "Analog output slope" setting).	Stored in configuration yes
		FLOAT32	Analog scaling offset point [mm]	
		FLOAT32	Analog scaling height point [mm]	

43 (0x2B)	W		Set analog out scale to MAX command Sets the analog output scaling to its maximum values. Set analog out scale to MAX command 1 Set analog out scale to MAX.	Stored in configuration no
----------------	---	--	--	-------------------------------

3.8 Diagnosis features

50 (0x32)	RW		Diagnose mode If diagnose mode is activated, the diagnosis features (live monitor and profile) can be used. During diagnose mode, all filters will be disabled and the outputs (analog and digital) will be set to fixed values. The standard measurement values are not accessible (index 21,22) and the laser can't be switched	Stored in configuration no
----------------	----	--	---	-------------------------------

			off (index 34).	
		UINT8	Diagnose mode 0 * Deactivated 1 Activated	

51 (0x33)	R		Live monitor The Live monitor values are based on the learned reference plane (Flex mount feature).	Stored in configuration no
		FLOAT32	Angle [deg]	
		FLOAT32	Center hight [mm]	
		FLOAT32	Left edge rising [mm]	

3.9 Configuration storage features

200 (0xC8)	W		Load configuration command Loads the selected configuration to ram (current configuration). For permanent storage of the loaded values, the "Store configuration command" has to be used.	Stored in configuration no
		UINT8	Configuration number 0 Active config 1 Config 1 2 Config 2 3 Config 3	

201 (0xC9)	W		Store configuration command Permanently stores the current configuration.	Stored in configuration no
		UINT8	Configuration number 0 Active config Current configuration will be stored to the active configuration. 1 Config 1 Current configuration will be stored to Config 1. 2 Config 2 Current configuration will be stored to Config 2. 3 Config 3 Current configuration will be stored to Config 3.	

202 (0xCA)	W		Reset to factory settings command All configurations will be reset to factory settings. The sensor will reboot after execution of this command.	Stored in configuration no
		UINT8	Reset to factory settings command 0 Reset to factory settings	

203 (0xCB)	R		Configuration 1 Values stored in configuration 1.	Stored in configuration no
		UINT8	Measurement type selection Measurement type to use for all outputs (Analog output, Digital output, LED's). 13 Height (AVG) 14 Height (MAX) 15 Height (MIN) 16 * Height (MAX-MIN)	
		UINT8	Object type 0 * Bright object 1 Dark object	
		UINT8	Precision 0 * Standard	



			1 High 2 Very high
		UINT8	Flex mount enable 0 * Disabled 1 Enabled
		FLOAT32	Angle Flex mount rotation angle [deg].
		FLOAT32	Distance Flex mount offset distance [mm].
		INT16	Limit left Field of view left limitation [mm].
		INT16	Limit right Field of view right limitation [mm].
		FLOAT32	Analog scaling offset point [mm]
		FLOAT32	Analog scaling height point [mm]
		UINT8	Analog output type 0 * Current 1 Voltage
		UINT8	Analog output slope Slope of the analog characteristic curve. Can be positive (minimum output at minimum measurement value, fullscale output at maximum measurement value) or negative (vice versa). 0 * Positive 1 Negative
		UINT8	Digital output type 0 * Point 1 Window
		UINT8	Digital output polarity 0 * Active high 1 Active low
		FLOAT32	Switch point 1 [mm]
		FLOAT32	Switch point 2 [mm]

204 (0xCC)	R	UINT8	Configuration 2 Values stored in configuration 2. Measurement type selection Measurement type to use for all outputs (Analog output, Digital output, LED's). 13 Height (AVG) 14 Height (MAX) 15 Height (MIN) 16 * Height (MAX-MIN)	Stored in configuration no
		UINT8	Object type 0 * Bright object 1 Dark object	
		UINT8	Precision 0 * Standard 1 High 2 Very high	
		UINT8	Flex mount enable 0 * Disabled	



			1 Enabled
		FLOAT32	Angle Flex mount rotation angle [deg].
		FLOAT32	Distance Flex mount offset distance [mm].
		INT16	Limit left Field of view left limitation [mm].
		INT16	Limit right Field of view right limitation [mm].
		FLOAT32	Analog scaling offset point [mm]
		FLOAT32	Analog scaling height point [mm]
		UINT8	Analog output type 0 * Current 1 Voltage
		UINT8	Analog output slope Slope of the analog characteristic curve. Can be positive (minimum output at minimum measurement value, fullscale output at maximum measurement value) or negative (vice versa). 0 * Positive 1 Negative
		UINT8	Digital output type 0 * Point 1 Window
		UINT8	Digital output polarity 0 * Active high 1 Active low
		FLOAT32	Switch point 1 [mm]
		FLOAT32	Switch point 2 [mm]

205 (0xCD)	R		Configuration 3 Values stored in configuration 3.	Stored in configuration no
		UINT8	Measurement type selection Measurement type to use for all outputs (Analog output, Digital output, LED's). 13 Height (AVG) 14 Height (MAX) 15 Height (MIN) 16 * Height (MAX-MIN)	
		UINT8	Object type 0 * Bright object 1 Dark object	
		UINT8	Precision 0 * Standard 1 High 2 Very high	
		UINT8	Flex mount enable 0 * Disabled 1 Enabled	
		FLOAT32	Angle Flex mount rotation angle [deg].	
		FLOAT32	Distance	

			Flex mount offset distance [mm].
		INT16	Limit left Field of view left limitation [mm].
		INT16	Limit right Field of view right limitation [mm].
		FLOAT32	Analog scaling offset point [mm]
		FLOAT32	Analog scaling height point [mm]
		UINT8	Analog output type 0 * Current 1 Voltage
		UINT8	Analog output slope Slope of the analog characteristic curve. Can be positive (minimum output at minimum measurement value, fullscale output at maximum measurement value) or negative (vice versa). 0 * Positive 1 Negative
		UINT8	Digital output type 0 * Point 1 Window
		UINT8	Digital output polarity 0 * Active high 1 Active low
		FLOAT32	Switch point 1 [mm]
		FLOAT32	Switch point 2 [mm]

206 (0xCE)	R		Active configuration Values stored in the active configuration (0).	Stored in configuration no
		UINT8	Measurement type selection Measurement type to use for all outputs (Analog output, Digital output, LED's). 13 Height (AVG) 14 Height (MAX) 15 Height (MIN) 16 * Height (MAX-MIN)	
		UINT8	Object type 0 * Bright object 1 Dark object	
		UINT8	Precision 0 * Standard 1 High 2 Very high	
		UINT8	Flex mount enable 0 * Disabled 1 Enabled	
		FLOAT32	Angle Flex mount rotation angle [deg].	
		FLOAT32	Distance Flex mount offset distance [mm].	
		INT16	Limit left Field of view left limitation [mm].	
		INT16	Limit right	

			Field of view right limitation [mm].
		FLOAT32	Analog scaling offset point [mm]
		FLOAT32	Analog scaling height point [mm]
		UINT8	Analog output type 0 * Current 1 Voltage
		UINT8	Analog output slope Slope of the analog characteristic curve. Can be positive (minimum output at minimum measurement value, fullscale output at maximum measurement value) or negative (vice versa). 0 * Positive 1 Negative
		UINT8	Digital output type 0 * Point 1 Window
		UINT8	Digital output polarity 0 * Active high 1 Active low
		FLOAT32	Switch point 1 [mm]
		FLOAT32	Switch point 2 [mm]

4 Example commands

Example commands with standard Device Address (01).

Command	Description
:01W010;0;E9C3\r\n	RS485 lock deactivated
:01R002;3955\r\n	Device Info (Article number, sensor type...)
:01R006;F957\r\n	Check Baud rate
:01W006;2;C1FF\r\n	Set Baud rate to 2 = 115'200
:01W011;1;85C3\r\n	Reactivate analog and digital sensor outputs
:01R021;09F4\r\n	Get the measuring value
:01R022;F9F4\r\n	Requesting all measuring values
:01W020;13;B1BE\r\n	Set measurement type to HEIGHT (AVG)
:01W020;14;81BC\r\n	Set measurement type to HEIGHT (MAX)
:01W020;15;11BD\r\n	Set measurement type to HEIGHT (MIN)
:01W020;16;E1BD\r\n	Set measurement type to HEIGHT (MAX-MIN)
:01W032;0;91BB\r\n	Set object type bright
:01W032;1;01BA\r\n	Set object type dark
:01W035;1;75BB\r\n	Enable FLEX MOUNT
:01W037;0;5DBB\r\n	Teach-In FLEX MOUNT to actual reference surface with a correction of 0mm
:01W201;0;37FE\r\n	Store active configuration permanent to sensor
:01W202;0;73FE\r\n	Reset to factory settings

5 Appendix

5.1 Dependencies

Because some commands are dependent on one another, they can be executed only if certain settings were configured in advance. Important: Before RS485 commands can be sent, RS485 must be unlocked via the command :01W010;0;E9C3\\n (010 RS485 lock).

		Input configuration		Output	
Index description					
Index no.		10	50	34	33
Configuration	locked				0 Application error
	unlocked				1 Vendor info
	off				2 Device info
	running				5 Bus address
	Standard				6 Baudrate
	not Standard				10 RS485 lock
	hold				11 Output reactivation
	Standard				15 Display language
	not Standard				16 Display backlight
	on				17 Touch button lock
					20 Measurement type selection
					21 Measurement value
					22 All measurement values
					30 Field of view
					31 Set field of view to max command
					32 Object type
					33 Precision
					34 Laser off data hold
					35 Flex mount enable
					36 Set flex mount
					37 Teach flex mount command
					40 Digital out configuration
					41 Analog out type
					42 Analog out scale
					43 Set analog out scale to max command
					50 Diagnose mode
					51 Live monitor
					200 Load configuration command
					201 Store configuration command
					202 Reset to factory settings command
					203 Configuration 1
					204 Configuration 2
					205 Configuration 3
					206 Active Configuration

Legend:
 Index locked
 Index unlocked

6 History of changes

Date	Version	Description
24.11.2015	1.0	Document created
10.08.2016	1.01	Renaming FLEX MOUNT "thickness" in "correction"
07.06.2017	1.1	Chapter example commands implemented
17.01.2018	1.2	Dependency matrix changed



Baumer
Passion for Sensors

Baumer Group
International Sales
P.O. Box · Hummelstrasse 17 · CH-8501 Frauenfeld
Phone +41 (0)52 728 1122 · Fax +41 (0)52 728 1144
sales@baumer.com · www.baumer.com